

# WENDEL® LIGHTING

## RELAMPING INSTRUCTIONS FOR WENDELIGHTING® FRAMING PROJECTORS

Wendelighting® projectors use a mini-can quartz halogen lamp. Avoid touching the glass part of the lamp with bare hands as the oil from finger tips will adhere to the glass and lessen the life of the lamp. (For further preparation see direction for use located in lamp package.)

Disconnect power and make sure projector is cool to the touch of the hand. Relamping tube should not be used until burned out lamp no longer retains heat as it will melt plastic tube.

Place slotted end of tube through top opening of projector and slip it over lamp. Turn tube counter clockwise to loosen bulb. Remove burnt out bulb from tube. Place new lamp into slotted end of tube and turn into socket.

